Installation Tools

Only basic tools are required for installation of ControTrace/TraceBOOST. The following tools are recommended:

Banding

Banding Clamps

¾" to 1½" Ton Come Along

HTC

Rubber gloves

Ratchet and Socket 7/8"

Tyvek Suit

3" Putty Knife

Screwdriver

Tin Snips

Wrenches

Banding Tool

Hammer

Channel Lock Pliers

Tape Measure

Markers

Level

5/8"-(x2) 3/4" 7/8"-(x2) 1-1/16" 1-1/8" 1-1/4"